

DSSE

PRODUCT MANUAL



PHANTOM BARBER CHAIR BC31

Where Authority Meets Absolute Presence

The Phantom barber chair embodies the quiet confidence of an Italian Don. With its matte black steel frame and deep tufted button backrest, it fuses old-world elegance with modern authority. Every line, stitch, and curve is designed to project prestige. Built for barbers who value refinement, the Phantom delivers smooth movement, solid support, and lasting comfort wrapped in a bold, commanding presence. More than a chair, it's a statement of taste, power, and professionalism.

Introduction

This manual is intended solely as a reference for the operation of this specific model. DSSE assumes no responsibility or liability for any consequences resulting from its use for other purposes. All information contained in this manual is protected by copyright and may not be copied, reproduced, or translated, in whole or in part, without the prior written consent of our company.

Safety Instructions

- Ensure the barber chair is stable and positioned on a flat, level surface before use.
- Do not stand, climb, jump, or apply excessive force to any part of the chair, including the footrest, armrests, headrest, or backrest.
- Keep children away from the equipment at all times and never allow them to sit on or operate the chair unsupervised.
- When the chair is not in use, return it to a neutral, lowest, and safest position to reduce the risk of tipping or accidental movement.
- Do not use the chair in damp, wet, or high-humidity environments.
- Do not use the equipment in environments where painting, coating, spraying, or oxygen provision is taking place.
- Operation by inexperienced persons or those with physical, sensory, or mental impairments is permitted only under supervision.
- Ensure no objects, tools, cables, or body parts are within the chair's movement range during height, recline, or rotation adjustments.
- If any part is damaged or unstable, stop use immediately and contact your distributor or a qualified technician.
- Do not disassemble or modify the chair. Servicing must be carried out by authorised professionals only.
- Use only manufacturer-approved replacement parts to maintain safety, performance, and warranty validity.

Precautions

- Read this manual carefully before installation, operation, or adjustment, and retain it for future reference.
- This equipment must only be operated by trained or experienced personnel familiar with its structure, controls, and intended use.
- Do not apply uneven loads or use the barber chair for single-point loading, leaning, or misuse beyond seated professional services.
- Regularly inspect and tighten all bolts, screws, and fasteners to prevent loosening caused by movement or repeated adjustment.
- Do not disassemble, modify, or remove components without authorisation.
- Ensure the hydraulic or electric adjustment mechanisms are operated smoothly and never forced.
- If a fault, abnormal noise, leak or irregular movement is detected, stop use and have the chair inspected by a qualified technician.
- Only resume operation after the issue has been correctly identified and resolved.
- Observe and follow all warning labels and markings affixed to the product.
- Clean dust, hair, and stains using a neutral, non-abrasive cleaning agent after each service.
- Keep hands, feet, hair, and tools clear of moving parts during height, recline, or rotation adjustments.
- Always observe the maximum user weight specified in this manual.
- Do not sit, stand, or apply excessive force on the armrests, footrest, headrest, or backrest. Refer to the stated load limits.
- Ensure all locking, braking, and positioning mechanisms are fully engaged before seating or adjusting the client.
- For safety and stability, ensure the chair base, pump, and fixings are installed as outlined in the installation guide.
- Clients must enter and exit the chair using the seat and must not stand on the footrest.

Product Specifications

Height:	112-130cm
Seat Height:	54-72cm
Width (Total):	67cm
Width (Inner Seat):	50cm
Depth (Total):	97-151cm
Depth (Inner Seat):	49cm
Recline:	103°-134°
Net Weight:	75 kg
Gross Weight:	85 kg
Maximum Weight Capacity:	250 kg (seating position)




MAX WEIGHT
250 KG

Installation Preparation: Ensure you have a clean, level workspace with enough room to assemble the chair. Remove all parts from the packaging and check that all components are included and undamaged. Keep the hydraulic base upright and avoid placing heavy parts on unstable surfaces. Due to the weight of the chair, two-person assembly is recommended.

STEP 1

Using two people, lift the chair off the pallet and place it onto a clean, flat, stable surface.





Warning: Take care when tightening screws to avoid cross-threading.

STEP 2

Install the Footrest


Remove the pre-installed screws from the footrest (D). Position the footrest in place and use the same screws to secure it firmly.



STEP 3


Install the Backrest

Remove the pre-installed screws from the backrest (B). Position the backrest in place and use the same screws to secure it firmly.



STEP 4

Attach the levellers (C) underneath the footrest (D), ensuring they are adjusted to make firm contact with the floor for proper stability.



SAFETY WARNING: This barber chair is designed for professional use only. Ensure the chair is placed on a stable, level surface and never exceed the stated weight capacity. Keep children away from the chair at all times. Do not stand on the footrest or use the chair for any purpose other than seated grooming services.

Upholstery Care Guide

As a professional barber, investing in a high quality barber chairs can significantly enhance the comfort and effectiveness of your treatments. To maintain that level of performance and ensure long-term reliability, regular maintenance and proper care are essential. Like any professional equipment, your barber chair requires routine attention to stay in optimal working condition ensuring safety, smooth functionality, and a consistently elevated experience for your clients.

General Care Tips

Maintain a stable temperature:

- Cold can lead to vinyl cracking
- Heat may cause permanent stretching

Keep out of direct sunlight for long periods to prevent fading and damage. Regular housekeeping helps preserve comfort and appearance.



Cleaning Instructions

Clean the chair regularly and after each client to remove hair, body oils, and styling product residue.

Use a soft cloth with warm water and a mild, neutral cleaning agent only.

Wipe all vinyl, metal, and plastic surfaces thoroughly, then dry with a clean cloth.

Remove hair and debris from moving parts to prevent buildup and restricted movement.

For hygiene, a diluted, non-abrasive disinfectant suitable for vinyl may be used in accordance with the manufacturer's instructions.



Avoid Using These Products

- Hot or boiling water
- Alcohol or hydrocarbon-based cleaners
- Acetone
- Bleach or harsh detergents
- Furniture polish
- Abrasive powders, pastes, or steel wool
- Silicone or petroleum-based products
- Solvent-based or abrasive cleaning agents

Routine Inspection

Perform periodic checks on:

- Hinges
- Fasteners
- Structural components

Ensure your chair remains safe, stable, and fully functional.

Do not dispose of old or defective appliances with household waste. Please use designated public collection points for proper disposal. This manual is for reference only. Specifications may change without prior notice.

WARRANTY PERIOD

STRUCTURE: **5 YEARS** | VINYL: **2 YEARS** | HYDRAULIC PUMP: **2 YEARS**

For more information about our warranty, please refer to our website.

Australia:

www.dsse.com.au

United Kingdom:

www.dssebeauty.co.uk

Europe:

www.dsseworld.com