

DSSE

PRODUCT MANUAL



# SELENE MOON LIGHT ML10

---

## **For Brows That Deserve The Spotlight**

Light up every detail with the Selene Moon Light – the ultimate glow for flawless brows and beauty treatments. Designed to give crystal-clear lighting with adjustable brightness and soft, natural tones, it makes precision work effortless while keeping clients comfortable. Sleek, modern, and built to last, this is the perfect beauty light to elevate your space and your artistry.

## Disclaimer

This manual is provided solely as a reference for the safe and proper operation of this model and must not be used for any other purpose. DSSE accepts no liability for any incidental, indirect, or consequential damages arising from the use of this manual or the equipment described.

The information contained herein is subject to change without notice and does not constitute a commitment by DSSE. While every effort has been made to ensure accuracy, DSSE assumes no responsibility for errors or omissions, nor any expressed or implied warranties, including but not limited to merchantability or fitness for a particular purpose. All content is protected by copyright law and may not be copied, reproduced, distributed, or translated, in whole or in part, without prior written authorisation from DSSE.

## General Cleaning

- ▮ Routine care – Dust regularly with a soft, dry cloth to prevent buildup.
- ▮ Switch off power before cleaning. Use a soft, damp cloth on external surfaces only. Avoid moisture near the light and electrical components. Wipe dry immediately.
- ▮ Avoid abrasive materials or harsh cleaners, as they may damage the surface.
- ▮ Test first – Always test any new cleaning product on a small, hidden area before full use.

## Safety Information

- ▮ To ensure safe use of this product, please observe the following precautions:  
Keep children away from the equipment; place it out of their reach.
- ▮ Use only as intended – The product must only be used for its designed purpose. Misuse may result in injury or damage.
- ▮ Always position the base and lamp in the same direction for stability.
- ▮ Do not hang or attach items to the lamp.
- ▮ Keep away from moisture and high-temperature areas.
- ▮ Avoid direct contact with the lamp during operation.
- ▮ Avoid modifications – Do not alter or tamper with the product, as this may compromise safety and void the warranty.
- ▮ Professional use only – This product is intended for professional salon/clinic environments and should only be operated by trained personnel.

## Maintenance

- ▮ Regularly inspect all components and fasteners to ensure your product remains structurally sound and fully functional.
- ▮ Wipe the lamp body, stand, and lamp head with a soft microfiber cloth. Avoid abrasive or chemical cleaners.
- ▮ Keep ventilation openings on the lamp head free from dust and debris to prevent overheating.
- ▮ Check all joints, rotation points, and height-adjustment locks periodically. Tighten gently if any parts feel loose.
- ▮ Ensure the heavy base stays clean and stable, and that nothing underneath affects balance.
- ▮ Rotate and adjust the lamp head and stand carefully to avoid strain on internal components.
- ▮ Stop using the lamp if you notice flickering, unstable rotation, overheating, or unusual noises.
- ▮ All maintenance should be carried out by a suitably qualified technician or tradesperson.

### WARRANTY PERIOD : - STANDARD: 12 MONTHS


For more information about our warranty, please refer to our website.

### Lock Screw

Secures the lamp head firmly in place, ensuring stability and preventing movement during use.

### Switch Knobs (x 2)

Turn the power knob to switch the lamp on and adjust the brightness. The CCT knob allows colour temperature adjustment from 2700K to 5600K.



### Stand (Part B)

### Lock Dial

Adjusts and secures the height of the Moon Light, allowing you to set it at the perfect working level.

### Stand (Part C)

### Base

A slimline, heavy-duty foundation designed to support the full weight of the light and maintain stability during use.

### Stand (Part A)


## Technical Data

Model:	<b>ML-10</b>
Input Power:	<b>110V-240V, 50/60Hz</b>
Output Power:	<b>40W</b>
Colour Temperature:	<b>2700K - 5600K</b>
CRI:	<b>&gt; 95</b>
Lumen Output:	<b>1600LM</b>
Lifespan:	<b>5,000 hours</b>
Dimensions:	Height: 121-176cm Width: 92cm Depth: 25cm
Weight:	<b>10kg</b>

## STEP 1

### Connecting the Head


Attach the lamp head to Stand **A**. Rotate and tighten the lamp head until it is secure. Insert the lock screw to firmly hold the lamp head in place.



## STEP 2

### Connecting the Power Cable


Stretch the power cable with your arms wide apart to remove any twists. Once fully extended, insert the cable through the stand tube and guide it downward until it exits from the base.



## STEP 3

### Connecting the Stand and Lamp


Release the lock knob to extend the inner pole **B**. Screw inner pole **B** into Stand **A**, then securely tighten the lock dial to lock it in position.



## STEP 4

### Assembling the Base

Securely attach Stand **C** to the base and tighten the 3 screws firmly in place.



## STEP 5

### Connecting the Cable to the Adapter

Insert the cable into the DC port of the power adapter, then plug the AC side of the adapter into the power supply to activate the light.

